



3900 Series
Digital Radio Test Set
DMR Option Manual



3900 Series

Digital Radio Test Set

DMR Option Manual

PUBLISHED BY
VIAVI Solutions, Inc.

COPYRIGHT © VIAVI Solutions, Inc. 2020

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise without the prior permission of the publisher.

Re-Issued Jan 2020

Preface

SCOPE

This manual contains operational descriptions of the features contained in the 3900 Series DMR Test System Option. Refer to the 3900 Series Operation Manual for information regarding general Test Set operation.

NOMENCLATURE STATEMENT

The 3901, 3902, 3920 and 3920B Digital Radio Test Set is the official nomenclature for the test sets currently included in the 3900 Digital Radio Test Set Series. In this manual, 3900, unit or Test Set, refers to the 3901, 3902, 3920 and 3920B Digital Radio Test Sets unless otherwise indicated.

INTENDED AUDIENCE

This manual is intended for personnel familiar with the use of the 3900. Refer to the 3900 Series Operation Manual for information pertaining to Test Set operation.

TEST SET REQUIREMENTS

Refer to the 3900 Series Operation Manual for information on the following:

- Safety Precautions
- Power Requirements
- Platform Performance Data Specifications
- Repacking/Shipping Test Set

THIS PAGE INTENTIONALLY LEFT BLANK.

Contents

CHAPTER 1 DMR GENERAL DESCRIPTION

Chapter describes DMR System capabilities and system access.

CHAPTER 2 DMR SYSTEM TILES

Chapter describes DMR System function tiles.

CHAPTER 3 DMR CHANNEL LOGGER

Chapter describes DMR System Channel Logger function.

CHAPTER A DMR TERMS AND ABBREVIATIONS

Chapter describes DMR System terms and abbreviations.

THIS PAGE INTENTIONALLY LEFT BLANK.

Table of Contents

DMR General Description	1 - 1
DMR Option Overview	1 - 1
Scope of Manual	1 - 1
DMR Option Status	1 - 2
Factory Installed Option	1 - 2
Post Production Option	1 - 2
Verifying DMR Option Installation	1 - 2
DMR System Tiles	2 - 1
Introduction	2 - 1
DMR System Tile Layout	2 - 1
Audio Signal Routing	2 - 2
Audio/Demod Signal Routing	2 - 2
DMR Configuration Tiles	2 - 3
AutoTune Setup Configuration Tile	2 - 3
DTMF Configuration Tile	2 - 4
Offsets Configuration Tile	2 - 5
Offsets Cable Loss Measurements	2 - 6
UUT Measurements Limits Configuration Tile	2 - 8
DMR Test Tiles	2 - 9
Advanced Analysis Tile	2 - 9
Audio Input Tile	2 - 10
Audio Generator Tile	2 - 11
Constellation Tile	2 - 13
Decode Tile	2 - 14
Distribution Tile	2 - 15
Eye Diagram Tile	2 - 16
Generator Modulation Tile	2 - 17
Power Over Time Tile	2 - 19
Power Profile Full	2 - 21
Power Profile Ramps	2 - 24
RF Control Tile	2 - 26
UUT Measurements Tile	2 - 31

DMR Channel Logger 3 - 1

 Introduction 3 - 1

 Viewing Application 3 - 1

 Connecting Equipment 3 - 1

 DMR XML Command Structure 3 - 2

 <burst></burst> 3 - 2

 Filter Parameters 3 - 3

 <LogFilter></LogFilter> 3 - 3

Sample Setup File 4 - 1

 DMR Test Setup Sample Configuration File 4 - 1

DMR Terms and Abbreviations A - 1

Chapter 1 - DMR General Description

1.1 DMR OPTION OVERVIEW

The 3900 Digital Mobile Radio (DMR) Test System (390XOPT400) is an optional test system developed by VIAVI to support the testing of digital two-way radio systems. DMR has been developed according to technical specifications outlined in ETSI TS 102 361-1, V1.4.1.

The 3900 DMR Test System Option provides the user with the following capabilities:

- Ability to lock/unlock paired generator and receiver frequencies;
- Ability to receive, demodulate and analyze DMR modulated signals;
- Ability to perform RF and modulation parametric tests on the Unit Under Test (UUT).
- Ability to select DMR or Analog Protocols;
- Distribution, Constellation and Eye Diagram graph plots;
- Variety of UUT measurements including Bit Error Rate, Signal Power, Slot Power, Frequency Error, Symbol Clock Error, Symbol Deviation and FSK Error;
- Power Profile Over Time, Profile Full and Profile Ramps Display Tiles;
- Spectrum Analyzer, Channel Analyzer and Oscilloscope available within the DMR Test System.

1.2 SCOPE OF MANUAL

The 3900 Digital Mobile Radio (DMR) Option Manual describes functions associated with the 3900 Digital Mobile Radio (DMR) Test System. Refer to the 3900 Operation Manual for use of the following inherent base functions:

- Test Set Instruments
- Tone Encoding
- Tone Decoding
- Frequency List

1.3 DMR OPTION STATUS

1.3.1 Factory Installed Option

When DMR is purchased as a factory installed option the DMR Software Option is ready to use upon receipt.

1.3.2 Post Production Option

When the DMR Software Option is purchased post production the option software and option license files must be installed in the Test Set. Refer to the 3900 Operation Manual for Option Installation and Software Upgrade Procedures.

1.3.3 Verifying DMR Option Installation

To check the status of installed options when operating in Test Mode:

STEP	PROCEDURE
------	-----------

1. Push the UTILS Soft Key twice to access the Utils floating menu.
2. Select Software Settings, License from the floating menu.

The License Tile displays a list of installed options (refer to Fig. 1-1). DMR is 390XOPT400. The option list varies according to the features installed on the Test Set. "Try before you buy" options have an expiration date.

NOTE The Software Upgrade Tile also contains a list of installed options as well as the software version.




Fig. 1-1 3900 License Tile

Chapter 2 - DMR System Tiles

2.1 INTRODUCTION

This chapter describes DMR Tile layout and provides an operational description of DMR System Tiles.




Fig. 2-1 DMR Tile Layout

2.2 DMR SYSTEM TILE LAYOUT

The DMR Display Tiles can be configured according to test requirements. Each section of the display is configured using the drop-down menu on the title bar of each tile.

- Section A of the DMR User Screen always displays the RF Control Tile when the Tiles are minimized.
- DMR Test functions are selected from the drop-down menu located on the Tile menus on Sections B through E.
- DMR includes access to the Channel Analyzer, Spectrum Analyzer and Oscilloscope. Use of the Channel Analyzer, Spectrum Analyzer and Oscilloscope are described in the 3900 Series Operation Manual.

2.3 AUDIO SIGNAL ROUTING

2.3.1 Audio/Demod Signal Routing

Audio/demod signal routing is configured by pressing the Assign Key on the Front Panel. Pressing the Assign Key displays a group of soft keys. The Speaker Toggle Soft Key selects the source and routing of the demod/audio signal applied to the Test Set's loudspeaker.




Fig. 2-2 Assign Key - Soft Key Sub-menu

2.3.1.A Field Definitions

2.3.1.A.1 Off

No audio input is being routed to the speaker.

2.3.1.A.2 Audio

Routes the incoming signal from the Audio Input connector to the speaker.

2.3.1.A.3 Demod

Routes the incoming signal from the FGEN Connector to the speaker.

2.4 DMR CONFIGURATION TILES

2.4.1 AutoTune Setup Configuration Tile

The AutoTune Setup Tile allows the user to configure functional parameters for the RF Analyzer AutoTune feature.

Fig. 2-3 AutoTune Setup Configuration Tile

2.4.1.A Field Definitions

2.4.1.A.1 AutoTune Threshold

When Autotune is selected the Test Set sets the RF Analyzer frequency to the strongest signal detected at the active RF Input connector. This reading defines an acceptable signal level in dBm's for successful detection on the ANT (Antenna) Connector. Default setting is -100 dBm on the ANT (Antenna) Connector which reflects -60 dBm on the T/R Connector.

2.4.1.A.2 AutoTune Start Freq

Sets the lower frequency at which AutoTune sweeps start.

2.4.1.A.3 AutoTune Stop Freq

Sets the upper frequency at which AutoTune sweeps stop.

2.4.1.A.4 AutoTune Freq Resolution

AutoTune Frequency Resolution defines the unit of measure a frequency is rounded to when AutoTune is enabled.

For example, if AutoTune Frequency Resolution is set to 1000 Hz, and the 3900 identifies a frequency as 151.625020 MHz, the frequency would be rounded to 151.625000 MHz and Frequency Error meter would be 20 Hz.

2.4.2 DTMF Configuration Tile

The DTMF Configuration Tile contains parameters that are used by the Test Set's Generators when sending DTMF tones. DTMF Waveform must be selected on the Generators Tile for parameters to apply.

The screenshot shows a software interface for configuring DTMF tones. It is titled "DTMF" and is divided into two main sections: "Mod Generator" and "AF Generator". Each section contains four parameters: "Mark Time" (set to 100), "Space Time" (set to 90), "End Time" (set to 500), and "Mode" (set to Single). The "RF" button at the bottom of the interface is highlighted in yellow, indicating it is the active configuration.

Fig. 2-4 DTMF Configuration Tile

2.4.2.A Field/Soft Key Definitions

2.4.2.A.1 Mark Time

Mark Time sets time period in which the DTMF tone is ON. Defined in milliseconds.

2.4.2.A.2 Space Time

Space Time sets dead time between DTMF tones of a sequence. Defined in milliseconds.

2.4.2.A.3 End Time

End Time sets dead time between complete DTMF sequences. This parameter is only valid when Continuous Mode of operation is selected.

2.4.2.A.4 Mode

Mode selects how many DTMF pulses are sent (Single or Continuous).

2.4.3 Offsets Configuration Tile

The Offsets Configuration Tile allows users to define Generator (Tx) and Receiver (Rx) Level offsets.




Fig. 2-5 Offsets Configuration Tile

2.4.3.A Field/Soft Key Definition

2.4.3.A.1 Tx Offset Level

Defines RF Generator Level Offset value.

2.4.3.A.2 Rx Offset Level

Defines Receiver Level Offset value.

2.4.3.A.3 TX Offset/Rx Offset Soft Keys

Enables/Disables defined Tx and Rx offset values.

2.4.4 Offsets Cable Loss Measurements

The Cable Loss Measurements functionality provides users with the ability to use the Test Set's Tracking Generator to evaluate a test cable in order to compensate for any cable loss and to characterize attenuators and other devices which impart a gain or loss.

NOTE Cable Loss Measurements are enabled when the 3900 Tracking Generator Option is installed in the Test Set.

2.4.4.A Field/Soft Key Definitions

2.4.4.A.1 Cable Loss File Menu

The Cable Loss File Menu is enabled when the Tracking Generator Option is installed in the Test Set. This menu loads a stored Cable Loss trace file which contains data that defines the RF Generator or RF Analyzer Level Offset by the offset value in the Cable Loss Trace.




Fig. 2-6 Cable Loss Parameters Enabled

NOTE The Cable Loss File Menu is only populated when one or more Cable Loss traces has been created.

2.4.4.A.2 Cable Loss Soft Key

The Cable Loss Soft Key is enabled when the Tracking Generator Option is installed in the Test Set. The Cable Loss Soft Key accesses soft keys which are used to create tables of amplitude loss for up to three test cables of different configurations.




Fig. 2-7 Cable Loss Tables

Pressing the Cable Loss 1, 2 or 3 Soft Key initiates a guided procedure for defining a cable loss table. The Test Set provides a series of on-screen instructions that the user follows to create each table.

NOTE

Cable Loss files are stored in the Test Set's Cable Loss Files directory.

Stored Cable Loss Files can be transferred from one Test Set to another using the File Management Tile. The receiving Test Set must have the Tracking Generator Option installed in order to transfer the files.

Transferred files must be placed in the receiving Test Set's Cable Loss Files directory in order for the file to be accessible.

2.4.5 UUT Measurements Limits Configuration Tile

The UUT Measurement Configuration Tile allows the user to define limits for UUT Measurements meter readings.

Measurement Type	Units	Upper Limit	Lower Limit	Averages	Disabled
Audio Distortion	%	0.00	0.00	1	Disabled
Audio Frequency	kHz	0.000	0.000	1	Disabled
Audio Level	V	0.00	0.00	1	Disabled
Audio SINAD	dB	0.00	0.00	1	Disabled
Audio SNR	H & N	0.00	0.00	1	Disabled
Broadband Power	W	100	100	1	Disabled

Fig. 2-8 UUT Measurements Limits Configuration Tile

2.4.5.A Field/Soft Key Definitions

2.4.5.A.1 Disabled/Enabled

The Enable/Disable Toggle button turns defined limits on and off. Default values are applied if values are not defined by user.

2.4.5.A.2 Upper Limit

The Upper Limit function sets a maximum acceptable reading for a specific measurement. When a measured level exceeds the enabled Upper Limit, the Meter Bar and reading background on the Measurement Tiles turns RED.

When readings within enabled Upper and Lower limits the Meter Bar and reading background on the Measurement Tiles turns GREEN.

2.4.5.A.3 Lower Limit

When a measured level drops below the enabled Lower Limit, the Meter Bar and reading background of the Measurement Tiles turns BLUE.

When readings within enabled Upper and Lower limits the Meter Bar and reading background on the Measurement Tiles turns GREEN.

2.4.5.A.4 Units

Selects the unit of measurement for applicable measurement.

2.4.5.A.5 Averages

Specifies the number of bursts over which data is averaged for each measurement. Values can be set independently for each meter. If the Averages field is set to 50, the Test Set averages data over 50 samples.

2.4.5.A.6 Set All Averages To Soft Key

Specifies the number of bursts over which data is averaged for all measurements. Values can also be set independently for each meter.

2.5 DMR TEST TILES

2.5.1 Advanced Analysis Tile

The DMR Advanced Analysis Tile displays parametric readings and frequency data which allows the user to quickly evaluate radio signal quality. The FSK Error Meter on the UUT Measurements Tile provides a summary of the data found on the Advanced Analysis Tile. The measurement meters on the left of the Advanced Analysis Tile display the same data as the meters on the UUT Measurements Tile. The Symbol Deviation data includes specified target values, actual values and percentage error values. Positive and negative symbol peak data corresponds to the positive and negative peaks on the Distribution Tile (Fig. 2-10). The Symbol Deviation data also includes Symbol Magnitude Error, Magnitude Peak and 4FSK Peak Error values.




Fig. 2-9 Advanced Analysis Tile - Maximized View




Fig. 2-10 Advanced Analysis and Distribution Tiles Selected

2.5.2 Audio Input Tile

The Audio Input Tile contains parameters for configuring audio signal routing.

NOTE

The Rx Protocol field on the RF Control Tile must be set to Analog in order to perform Audio Measurements.




Fig. 2-11 Audio Input Tile

2.5.2.A Field Definitions

2.5.2.A.1 Source

Selects the Audio input source.

2.5.2.A.2 Int Load

Selects either the 10 kOhm or 600 Ohm internal load to be applied at the Audio 1 or Audio 2 Input. Audio Balanced Input applies a fixed internal load of 600 Ohms.

2.5.2.A.3 External Load

The 3900 allows the user to define an external load value which is applied at the Audio 1 or Audio 2 Input ports. The external load value is applied to AF Level dBm or Watt measurements when the External Load is enabled.

2.5.2.A.4 External Load

The Ext Load toggle button enables/disables the use of an external load.

2.5.2.A.5 Filter

Selects a measurement filter to include in the measurement path.

2.5.2.A.6 Psoph

Selects CMESS or CCITT Psophometric weighting filter when the Psoph filter is selected from any of the Filter selection drop-down menus. Psoph filters are typically used for SINAD measurements, either Demod or Audio.

2.5.3 Audio Generator Tile

The Audio Generator Tile defines audio generator parameters for use in testing Analog radio systems. Parameters can be defined separately for each generator. The Test Set is configured to allow the user to simultaneously enable the audio generators on the Audio Generators Tile and the modulation generators on the Generator Modulation Tile.




Fig. 2-12 Audio Generator Tile

2.5.3.A AF Generator Field Definitions

2.5.3.A.1 A1, A2, A3 Toggle Buttons

The A1, A2 and A3 toggle buttons enable/disable corresponding audio generator. AF Generators can be enabled in combination or individually.

2.5.3.A.2 Frequency

Sets the frequency for each AF generator. Frequency can be specified in kHz or Hz as defined by user.

2.5.3.A.3 Amplitude

Defines the amplitude for each AF Generator. Amplitude can be specified in V or mV as defined by user.

2.5.3.A.4 Waveform

Defines the Waveform for each AF Generator.

2.5.3.A.5 Sequence

The Sequence field is enabled when DTMF Waveform is selected. The field defines/indicates the DTMF Sequence of the DTMF Waveform.

2.5.3.A.6 CODE

The Code field is enabled when DCS or DCSINV Waveform is selected. The field defines/indicates the DCS codeword of the generated signal.

2.5.3.A.7 Output Port

Setting the Output Port to AF Out routes the output from the AF Generators to the FCTN GEN/Demod Connector. Selecting Demod Out routes the demodulated audio signal to the FCTN/GEN Demod Out Connector.

2.5.3.A.8 Impedance

Defines the external termination value used to calculate the AF Generator power level.

2.5.4 Constellation Tile

The Constellation tile is used to determine proper operation of the transmitter. The four points represent the four deviation states (DIBIT Symbols) of the DMR FSK modulation shown below. The green plot fields indicate the expected location of plot clusters.

Information Bits	Symbol	4FSK Deviation
01	+3	+1.944 kHz
00	+1	+0.648 kHz
10	-1	-0.648 kHz
11	-3	-1.944 kHz

DIBIT Symbol Mapping to 4FSK Deviation




Fig. 2-13 Constellation Tile

2.5.4.A Field/Soft Key Definitions

2.5.4.A.1 Persistence


Specifies how many trace plots are shown simultaneously on the display field. Selectable range is 1 to 10. Selecting 1 means that only one burst or time slot is displayed on the display field. Selecting 10 means the last 10 bursts or time slots are displayed simultaneously on the display field.

2.5.4.A.2 Reset Meters Soft Key

The Reset Meters Soft Key clears and resets the meter readings.

2.5.5 Decode Tile

The Decode Tile displays digital data contained in the signal received from the UUT. Color Code, Call ID and Unit ID do not apply to all types of received signals. Fields appear blank when data is invalid and display --- when they are not applicable to the received signal.



The image shows a software interface titled "Decode". It features a light green background with a dark blue header bar containing the word "Decode" and a small red square icon. Below the header, there are four data fields arranged vertically: "Color Code" with the value "0", "Call ID" with the value "0", "Unit ID" with the value "16777016", and "Station ID" which is currently empty. At the bottom of the interface, there is a horizontal bar with three segments: "DMR" on the left, "INT" in the middle, and "Return" on the right, which is highlighted in yellow.

Fig. 2-14 Decode Tile

2.5.5.A Field/Soft Key Definition

2.5.5.A.1 Color Code

Field displays the Color Code the Test Set receives from the UUT.

2.5.5.A.2 Call ID

Field displays the Call ID the Test Set receives from the UUT.

2.5.5.A.3 Unit ID

Field displays the Unit ID the Test Set receives from the UUT.

2.5.5.A.4 Digital Station ID

Field displays the Digital Station ID the Test Set receives from the UUT.

2.5.6 Distribution Tile

The Distribution Tile shows the relative number of symbols in relation to each other. The plot shows the four deviation points and the level of symbols accumulated over 38 slots. For example, a higher level on the +1 or 648 Hz deviation point would indicate that more "00" information bits were received compared to the other deviation points.




Fig. 2-15 Distribution Tile - Maximized View

2.5.6.A Field/Soft Key Definitions

2.5.6.A.1 Persistence

Specifies how many trace plots are shown simultaneously on the display field. Selectable range is 1 to 10. Selecting 1 means that only one burst or time slot is displayed on the display field. Selecting 10 means the last 10 bursts or time slots are displayed simultaneously on the display field.

2.5.6.A.2 Reset Meters Soft Key

The Reset Meters Soft Key clears and resets the meter readings.

2.5.7 Eye Diagram Tile

The Eye Diagram is used to plot the demodulated signal from one slot of the DMR signal. The plot shows the demodulated signal periods from that slot which allows the user to observe the deviation accuracy of the demodulated signal at the symbol points. The point at which symbol deviation is measured is referenced to the symbol clock to determine the deviation of the waveform at the symbol time.




Fig. 2-16 Eye Diagram Tile - Maximized View - 2 Symbols

2.5.7.A Field/Soft Key Definitions

2.5.7.A.1 Number Symbols

Defines the horizontal scale of the display field. Lowering the number or symbols shows more detail of the signal pattern.

2.5.7.A.2 Reset Meters Soft Key

The Reset Meters Soft Key clears and resets the meter readings.

2.5.8 Generator Modulation Tile

The Generator Modulation Tile defines modulation generator parameters for use in testing Analog radio systems. Parameters can be defined separately for each modulator. The Test Set is configured to allow the user to simultaneously enable the modulation generators on the Generator Modulation Tile and the AF generators on the Audio Generators Tile.

	Freq	Dev	Mod Index	Wave
M1	Seq 01234567	2.500 kHz	1.667 %	DTMF
M2	Code 023	2.500 kHz	1.667 %	DCS
M3	3.4000 kHz	2.500 kHz	1.667 %	Sine
EXT	Audio 1	2.500 kHz	1.670 %	Hi Z - 10k

DMR INT Return

Fig. 2-17 Generator Modulation Tile

2.5.8.A Modulation Generator Field Definitions

2.5.8.A.1 M1, M2, M3 Buttons

The Modulator buttons enable/disable each modulator. Modulators can only be enabled one at a time.

2.5.8.A.2 Frequency

Sets the frequency for each Modulation generator.

2.5.8.A.3 Deviation

Defines the Deviation for each generator when FM modulation is selected. When this value is defined, the Modulation Index value updates to display the value as a percent.

2.5.8.A.4 Mod (Modulation) Index

The Mod Index field defines the modulation level as a percent of the maximum deviation setting (150 kHz). When a Mod Index value is entered, the Deviation value updates to display the value in kHz. For example, when the Mod Index value is set to 100%, the Deviation value updates to 150 kHz, the maximum Deviation setting.

2.5.8.A.5 Waveform

Selects Waveform for each modulator.

2.5.8.A.6 Sequence

The Sequence field is enabled when DTMF Waveform is selected. The field defines/indicates the DTMF Sequence of the DTMF Waveform.

2.5.8.A.7 CODE

The Code field is enabled when DCS or DCSINV Waveform is selected. The field defines/indicates the DCS codeword of the generated signal.

2.5.8.A.8 EXT Toggle Button

The EXT Toggle Button enables/disables an external modulation source.

2.5.8.A.9 Source

Selects the Audio input source.

2.5.8.A.10 Impedance

External source can be set to un-terminated high impedance (Hi Z), or include a 600 Ohm termination (600 Ohms).

2.5.9 Power Over Time Tile

The Power Over Time Tile displays the power measurement of the received signal over a specified period of time. This measurement provides an indication of the transmitter's stability.




Fig. 2-18 Power Over Time Tile

2.5.9.A Field/Soft Key Definitions

2.5.9.A.1 Mkr1/Mkr2

The Mkr1 and Mkr2 toggle buttons enable Marker 1 and Marker 2. Markers must be enabled to edit the Marker position fields. Status and functionality of these toggle buttons is linked to the Marker 1 and Marker 2 Soft Keys.

2.5.9.A.2 Marker Position

The Position Field allows the user to enter a value to specify Marker position on the graph field. A marker must be enabled and selected before this field can be edited.

2.5.9.A.3 Power Measurement

The data fields beside each marker position field indicate the power reading at the signal point.

2.5.9.A.4 Marker Delta

When both markers are defined and enabled the Delta field indicates the difference between the position and power measurement at each point on the signal.

2.5.9.A.5 Span

Span sets the length of time (horizontal scale) over which the power measurement is displayed. Maximum Span setting is 1800 seconds.

2.5.9.A.6 Marker 1/Marker 2 Soft Key

The Marker 1 and Marker 2 Soft Keys enables or disables the corresponding marker. Markers can also be enabled using the Marker On/Off toggle button.

2.5.9.A.7 Toggle Marker Soft Key

The Toggle Marker Soft Key changes focus between Marker 1 and Marker 2 when both markers are enabled. The Toggle Marker Soft Key also controls the marker readings displayed at the top of the minimized tile. Each press of this Soft Key changes the source of the measurements through Mkr1, Mkr2 and Delta readouts.

2.5.9.A.8 Reset Meters Soft Key

The Reset Meters Soft Key clears and resets the meter readings.

2.5.10 Power Profile Full

The Power Profile Full Tile displays the complete profile of the signal's power reading over a period of time.




Fig. 2-19 Power Profile Full - Maximized View

2.5.10.A Field/Soft Key Definitions

2.5.10.A.1 Mkr1/Mkr2

The Mkr1 and Mkr2 toggle buttons enable Marker 1 and Marker 2. Markers must be enabled to edit the Marker position fields. Status and functionality of these toggle buttons is linked to the Marker 1 and Marker 2 Soft Keys.

2.5.10.A.2 Horizontal Position

The Position Field allows the user to enter a value to specify Marker position on the graph field. A marker must be enabled and selected before this field can be edited.

2.5.10.A.3 Power Reading

The field to the right of the Horizontal Position field indicates the Power reading at the marker's position.

2.5.10.A.4 Marker Delta

When both markers are defined and enabled the Delta field indicates the difference between the position and power measurement at each point on the signal.

2.5.10.A.5 Persistence

Specifies how many trace plots are shown simultaneously on the display field. Selectable range is 1 to 10. Selecting 1 means that only one burst or time slot is displayed on the display field. Selecting 10 means the last 10 bursts or time slots are displayed simultaneously on the display field.

2.5.10.A.6 Slot

The Slot drop-down menu selects the Slot (0 or 1) for which data is being displayed on the plot and measurement fields.

2.5.10.A.7 Marker 1/Marker 2 Soft Key

The Marker 1 and Marker 2 Soft Keys enables or disables the corresponding marker. Markers can also be enabled using the Marker On/Off toggle button.

2.5.10.A.8 Toggle Marker Soft Key

The Toggle Marker Soft Key changes focus between Marker 1 and Marker 2 when both markers are enabled. The Toggle Marker Soft Key also controls the marker readings displayed at the top of the minimized tile. Each press of this Soft Key changes the source of the measurements through Mkr1, Mkr2 and Delta readouts.

2.5.10.A.9 Adjust Vertical Soft Key

The Adjust Vertical soft key opens a soft key sub-menu. The sub-menu soft keys adjust the position of the Vertical Scale and appearance of the signal on the graph. Scale is adjusted in increments of 10 dBm.




Fig. 2-20 Power Profile Full - Adjust Vertical Soft Key Sub-menu

2.5.10.A.10 Reset Vertical Soft Key

Resets all vertical values to default values and centers trace pattern vertically on the graph field. This soft key is accessed by pressing the Adjust Vertical Soft Key.

2.5.10.A.11 Adjust Horizontal Soft Key

Adjust Horizontal soft key opens a soft key sub-menu that allows users to adjust the position and range of the graph's horizontal scale. This feature can be used to focus on specific time spans of the slot, such as the first 2 ms (msec) or the last 5 ms (msec).

The largest range setting for Outbound and Inbound Reserved signal is 0 to 30 ms. The largest range setting for Inbound Random signals is 0 to 10 ms. The smallest range setting is 2 ms.




Fig. 2-21 Power Profile Full Adjust Horizontal Soft Key Sub-menu

2.5.10.A.12 Reset Horizontal Soft Key

Resets the horizontal scale to default settings. This soft key is accessed by pressing the Adjust Horizontal Soft Key.

2.5.10.A.13 Reset Meters Soft Key

The Reset Meters Soft Key clears and resets the meter readings.

2.5.11 Power Profile Ramps

The Profile Ramps Tile displays the ramp profile of the signal's power reading over one slot. The left side of the field provides a detailed view of the first 2 ms (msec) of the slot. The right side of the field provides a detailed view of the last 2 ms (msec) of the slot.




Fig. 2-22 Power Profile Ramps

2.5.11.A Field/Soft Key Definitions

2.5.11.A.1 Mkr1/Mkr2

The Mkr1 and Mkr2 toggle buttons enable Marker 1 and Marker 2. Markers must be enabled to edit the Marker position fields. Status and functionality of these toggle buttons is linked to the Marker 1 and Marker 2 Soft Keys.

2.5.11.A.2 Horizontal Position

The Position Field allows the user to enter a value to specify Marker position on the graph field. A marker must be enabled and selected before this field can be edited.

2.5.11.A.3 Power Reading

The field to the right of the Horizontal Position field indicates the Power reading at the marker's position.

2.5.11.A.4 Marker Delta

When both markers are defined and enabled the Delta field indicates the difference between the position and power measurement at each point on the signal.

2.5.11.A.5 Persistence

Specifies how many trace plots are shown simultaneously on the display field. Selectable range is 1 to 10. Selecting 1 means that only one burst or time slot is displayed on the display field. Selecting 10 means the last 10 bursts or time slots are displayed simultaneously on the display field.

2.5.11.A.6 Slot

The Slot drop-down menu selects the Slot (0 or 1) for which data is being displayed on the plot and measurement fields.

2.5.11.A.7 Marker 1/Marker 2 Soft Key

The Marker 1 and Marker 2 Soft Keys enables or disables the corresponding marker. Markers can also be enabled using the Marker On/Off toggle button.

2.5.11.A.8 Toggle Marker Soft Key

The Toggle Marker Soft Key changes focus between Marker 1 and Marker 2 when both markers are enabled. The Toggle Marker Soft Key also controls the marker readings displayed at the top of the minimized tile. Each press of this Soft Key changes the source of the measurements through Mkr1, Mkr2 and Delta readouts.

2.5.11.A.9 Adjust Vertical Soft Key

The Adjust Vertical soft key opens a soft key sub-menu. The sub-menu soft keys adjust the position of the Vertical Scale and appearance of the signal on the graph. Scale is adjusted in increments of 10 dBm.




Fig. 2-23 Power Profile Ramps - Adjust Vertical Soft Keys Sub-menu

2.5.11.A.10 Reset Vertical Soft Key

Resets all vertical values to default values and centers trace pattern vertically on the graph field. This soft key is accessed by pressing the Adjust Vertical Soft Key.

2.5.11.A.11 Reset Meters Soft Key

The Reset Meters Soft Key clears and resets the meter readings.

2.5.12 RF Control Tile

The RF Control Tile configures the Test Set for testing the physical layer of DMR radio systems. RF Control Tile fields must be configured according to the operating parameters of the Unit Under Test (UUT) to obtain valid test data. Available fields are dependent on the selected Protocol.




Fig. 2-24 RF Control Tile - DMR Protocol

2.5.12.A Transmit Field Definitions

2.5.12.A.1 Frq/Freq (Frequency)

The Transmit Frequency defines carrier frequency of the DMR signal being generated by the Test Set and is used to determine proper receiver operation. When used in conjunction with the Level, it is also used to determine UUT sensitivity by selecting the STD IB 1031 pattern.

2.5.12.A.2 Level

Level defines the output power of the 3900 DMR transmit signal from either the T/R or the GEN Connector. This is typically used to determine UUT receiver sensitivity using the STD IB 1031 pattern.

2.5.12.A.3 PD / EMF

When the RF Output Level unit of measurement is Volts, the value can be displayed as EMF or PD.

2.5.12.A.4 Units (Level)

The units drop-down menu selects the output power level unit of measure.

2.5.12.A.5 CC

The CC field defines the radio's Color Code.

2.5.12.A.6 Slot

The Transmit Slot selects either Slot 1 or Slot 2 for the transmit channel when the Mode Soft Key is set to SYNC (Synchronized).

When the Mode Soft Key is set to DIRECT, the Test Set transmits an unsynchronized signal which does not include the Slot parameter (Tx Slot must be defined). When SYNC Mode is selected the Tx and Rx Slot fields change to read only fields which display the slot number that last selected.

2.5.12.A.7 Call ID

The Call ID field defines the radio's Call Identification value. This parameter is also referred to as the Destination ID or Group Address.

2.5.12.A.8 Protocol

Defines Protocol for Transmit Channel.

2.5.12.A.9 Pattern

The Pattern drop-down menu selects the type of pattern the Test Set sends to the UUT.

Stored Speech

The Stored Speech Pattern is a digitized input source which is used to simulate the sounds generated in the payload for a burst.

STD Silence

The STD Silence Pattern is a test pattern which does not include sound in the payload field of a burst.

STD IB 511 (O.153)

The STD IB 511 Pattern is a test pattern that uses the O.153 standard pattern in the payload field of an Inbound burst. The STD IB 511 Pattern was implemented for future use.

STD IB CAL Pattern

The STD IB CAL Pattern is a test pattern that introduces errors into the STD IB 511 Pattern at specified bit locations (every 100th Bit) in order to generate a 1% Bit Error Rate (BER). This pattern is typically used to verify a radio's ability to calculate BER.

STD IB 1031 Pattern

When the STD IB 1031 is selected as the Transmit Pattern, the Test Set generates a signal that should produce a 1031 Hz tone in the radio. The STD IB 1031 Pattern contains a Color Code and Call ID parameter that must be defined according to the UUT in order to produce the 1031 Hz tone on the radio.

Every radio uses a Color Code to identify a specific radio system. A radio is programmed to ignore radio activity that does not contain the matching Color Code. The radio is also programmed to listen to one or more Call IDs plus the "All Call" ID (16777215).

To establish a call and obtain valid call data, the CC field must be set to the Color Code of the UUT. The Call ID must be set to one of the radio's programmed Call IDs or to the All Call ID (16777215).

STD OB TSYNC

The STD OB TSYNC pattern allows a radio programmed with a transmit offset to synchronize with an Outbound channel and transmit back on an offset channel. The CC Field defines the Color Code transmitted in the Slot PDU.

NOTE

Tx Mode is not applicable when the STD OB TSYNC pattern is selected.

Voice

The Voice Pattern is a test pattern that uses external input to generate the payload for a burst.

2.5.12.B Receive Field Definitions

2.5.12.B.1 Frq/Freq (Frequency)

This field defines the receiver frequency. For accurate readings, this frequency should be set to the UUT transmit frequency.

2.5.12.B.2 Offset

When set to LOCK, changing the Receive or Transmit Frequency offsets the other frequency by the value specified in the Offset field. For example, setting the Receiver frequency to 150 MHz, with an offset of 2.5 MHz, results in the Transmit frequency updating to 152.5 MHz. Or, if the Transmit frequency is set to 150.0 MHz, with an Offset of 2.5 MHz, the Receive frequency updates to 147.5 MHz.

When set to UNLOCK, a value can be entered independently for either the Transmit Frequency or the Receiver Frequency.

2.5.12.B.3 Lock/Unlock

Locks/Unlocks frequency offset in relation to the Transmit and Receive frequencies.




Fig. 2-25 RF Control Tile - Analog Protocol

2.5.12.B.4 Slot

When the Mode Soft Key is set to DIRECT, the Test Set transmits an unsynchronized signal which does not include the Slot parameter (Tx Slot must be defined).

When SYNC Mode is selected the Tx and Rx Slot fields change to read only fields which display the slot number that last selected.

2.5.12.B.5 Receive Slot

The Receive Slot selects either Slot 1 or Slot 2 for the receive channel when the Mode Soft Key is set to SYNC (Synchronized). The Receive Slot updates to a read only field when Tx Mode is set to DIRECT.

2.5.12.B.6 Demod Filter

Parameter is enabled when Analog Protocol is selected. Selects a measurement filter to include in the receive signal path.

2.5.12.B.7 Psoph

Parameter is enabled when Analog Protocol is selected. Selects CMESS or CCITT Psophometric weighting filter when the Psoph filter is selected from any of the Filter selection drop-down menus. Psoph filters are typically used for SINAD measurements, either Demod or Audio.

2.5.12.B.8 IF Bandwidth

Parameter is enabled when Analog Protocol is selected. The IF BW field selects the IF Bandwidth Filter included in the demodulation path.

2.5.12.B.9 Protocol

Defines Protocol for Receive Channel.

2.5.12.C Soft Key Definitions

2.5.12.C.1 RF Gen Soft Key

Selects and indicates the On/Off state of the RF Generator output from the Test Set. When the generator is disabled, an RF OFF indicator is shown on the Tile.

2.5.12.C.2 RF Out Soft Key

Controls the RF Output signal routing. Select either the GEN (Generator) Connector or T/R Connector as RF Output port.

2.5.12.C.3 RF In Soft Key

The RF In Soft Key controls the RF Input signal routing. Select either the T/R Connector or ANT (Antenna) Connector as the RF Input port.

2.5.12.C.4 Tx Mode Soft Key

Selects the DMR signal mode of operation when an Inbound pattern is selected.

Direct Mode uses a free-running Inbound signal to evaluate mobile and base station performance.

Sync Mode synchronizes the timing of the Test Set's inbound signal with the outbound signal from a repeater. When Sync Mode is selected the Tx Slot drop-down menu is enabled which allows the user to select either Slot 1 or Slot 2 for the transmit channel.

2.5.12.C.5 Pre-Amp Soft Key

The 3900 is equipped with an internal 15 dB broadband amplifier that affects the T/R Connector and ANT (Antenna) Connector. When Pre-Amp is turned ON, the 3900 has a typical noise figure of -9 dB leading to a noise floor level of approximately -140 dBm in the Spectrum Analyzer (RBW = 300 Hz) and approximately -126 dBm for the Inband Power Meter (IF = 6.25 kHz). Using the Pre-Amp feature increases the sensitivity of the 3900.

NOTE

When Pre-Amp is used, special attention is required; it is a broadband amplifier and could lead to saturation or compression problems in the receiver chain if the signal of interest is very low, but a strong out of band signal is present.

2.5.12.C.6 Analyzers Soft Key

The Analyzer Soft Key selects the method of setting the RF input frequency (Autotune or Manual). When Autotune is selected the Test Set locks on to the strongest signal. Once the Test Set locks on to a frequency, it monitors the Inband/Broadband Power Meter depending on the selected RF Input connector. AutoTune parameters are configured on the AutoTune Setup Configuration Tile.

NOTE	Autotune is not supported for non-continuous time signals (i.e., TDMA).
-------------	---

T/R Connector

When the T/R Connector is selected Autotune monitors the Inband and Broadband Power Meter. If Inband Power drops below the dB threshold defined on the AutoTune Setup Configuration Tile, and BroadBand Power exceeds 3 dBm, a search is triggered and the Test Set again searches for the strongest signal with a power level above the defined threshold.

ANT Connector

When the ANT Connector is selected Autotune monitors the Inband Power Meter. If Inband Power drops below the dB threshold defined on the AutoTune Setup Configuration Tile, a search is triggered and the Test Set again searches for the strongest signal with a power level above the defined threshold.

2.5.13 UUT Measurements Tile

The UUT Measurement Configuration Tile allows the user to define limits for UUT Measurements meter readings.




Fig. 2-26 UUT Measurements Tile

2.5.13.A Field/Soft Key Definitions

2.5.13.A.1 min/avg/max Reading Indicators

These radio buttons select the reading displayed on the bar graphs and the reading displayed when the UUT Measurements Display Tile is minimized.

Selecting min displays the lowest recorded reading.

Selecting avg displays the average of all recorded readings over the period of defined bursts (default setting).

Selecting max displays the highest recorded reading.

2.5.13.A.2 Bar Graph

The METER BAR is a single, linear indicator that provides a visual measurement reading based on a user defined scale. Upper and lower limit indicators are set on the UUT Measurement Configuration Tile.

2.5.13.A.3 Scale

Defines the display of the METER BAR. User selection is made from a drop-down box offering the choice of Auto (default value) or a fixed value.

2.5.13.A.4 Reset Meters Soft Key

The Reset Meters Soft Key clears and resets the meter readings.

2.5.13.B Measurement Meters

The drop-down menu on each section of the UUT Measurements Tile selects the type of meter to be displayed in that section. The Audio and Demod meters are enabled when Analog protocol is selected on the Tx and Rx signals.

2.5.13.B.1 Audio Frequency Meter

The Audio Frequency Meter measures the frequency of the audio signal received at the Test Set's selected input connector (i.e., Audio 1 or MIC Connector).

2.5.13.B.2 Audio Level Meter

The Audio Level Meter measures the amplitude and audio signal received at the Test Set's selected input connector (i.e., Audio 1 or MIC Connector).

2.5.13.B.3 Broadband Power

The Broadband Power Meter measures input power levels at the T/R Connector over a range of 100 mW to 125 W. The Broadband Power Meter is frequency independent which allows the user to measure and align transmitter power settings without adjusting the 3900's receiver frequency to match the transmitter frequency.

2.5.13.B.4 Demod Frequency Meter

The Demod Frequency Meter measures the frequency of the demodulated signal received at the Test Set's selected input connector (i.e., Audio 1 or MIC Connector).

2.5.13.B.5 Distortion Meters (Audio/Demod)

The Audio Distortion Meter measures the amount of audio distortion a radio receiver may add to an audio signal during the demodulation process. The Demod Distortion Meter measures the amount of audio distortion created by a radio transmitter when an audio signal is modulated.

2.5.13.B.6 FM Deviation Meter

The FM Deviation Meter measures the amount of deviation present on an FM Modulated RF Signal received by the 3900. When Analog Protocol is selected, the FM Deviation Meter does not include a filter in the signal path.

2.5.13.B.7 Frequency Error

The Frequency Error Meter measures the frequency error of the incoming RF carrier signal. Frequency Error is calculated as the difference between the frequency of the received signal and the receive frequency defined on the RF Control Tile.

2.5.13.B.8 FSK Error

The FSK Error Meter measures RMS deviation error at the symbol deviation points of the UUT signal. FSK Error is measured over one 30 ms slot and is expressed as the percentage of the deviation.

One slot of Outbound traffic (signal generated by BR) contains 144 symbols; inbound traffic (signal generated by mobile) contains 132 symbols. FSK Error should not exceed 5%.

The Advanced Analysis Tile provides more detailed FSK Error measurements.

2.5.13.B.9 Hum & Noise Meters (Audio/Demod)

The Audio Hum & Noise Meter measures the amount of hum and noise a radio receiver may add to the audio signal during the demodulation process. The Demod Hum & Noise Meter measures the level of hum and noise created by a radio transmitter when an audio signal is modulated.

2.5.13.B.10 Inband Power Meter

The Inband Power Meter indicates the total power measurement of the selected channel in the received RF Signal. Analog Protocol must be selected to enable this meter.

2.5.13.B.11 Magnitude Error

The Magnitude Error Meter indicates the Root Mean Square (RMS) of the difference between the expected and the received magnitude values. The Test Set measures Magnitude Error in two steps. First the expected magnitude is calculated as the mean of the received magnitudes. Then the Magnitude Error is computed by finding the RMS of the differences between the received magnitudes and the previously calculated expected magnitude.

2.5.13.B.12 RF Error Meter

The RF Error Meter indicates the difference (frequency error) between the received RF signal and the defined receive frequency. RF Error measurements are only valid when Analog Protocol is selected. The accuracy of the RF Error Meter is defined by the Resolution drop-down menu.

2.5.13.B.13 Signal Power

The Signal Power Meter is a tuned power meter that indicates the amount of RF Energy that is contained within the 3900's selected receiver bandwidth (i.e., 12.5 kHz). The Signal Power Meter is tuned to a specific frequency, giving the ability to selectively measure the power of one channel when other channels are present.

Signal Power can be measured at the T/R or ANT Connector. The T/R Connector provides measurements from -60 to +51 dBm. The ANT Connector provides the ability to measure levels from -100 to +10 dBm.

Drop-down menu selects unit of measurement as dBm or Watts. When Watts is selected and the reading falls below 100 mW, the meter background turns GRAY, indicating the reading may be inaccurate. If this occurs, switch the unit of measurement to dBm to obtain an accurate reading.

2.5.13.B.14 SINAD Meter (Audio/Demod)

The AF SINAD Meter measures the receive quality of a radio receiver. The Demod SINAD Meter measures the quality of the incoming RF Signal being demodulated by the Test Set. This meter also measures the quality of a radio transmitter when an audio signal is modulated. Meter is enabled when Analog protocol is selected on the Tx and Rx signals.

2.5.13.B.15 Slot 1/Slot 2 Power

The Slot Power Meters indicate measurements for Slot 1 and Slot 2 of the DMR signal.

2.5.13.B.16 Slot Power Ratio

The Slot Power Ratio Meter displays the Power On/Off ratio between the Slot 1 and Slot 2 Power meters.

2.5.13.B.17 SNR Meter (Audio/Demod)

The Audio/Demod SNR Meters can be configured for Hum and Noise or Normal SNR measurements. Analog Protocol must be selected to enable these meters. Hum and Noise enables a Reference Lock button on the meter.

2.5.13.B.18 Symbol Clock Error

The Symbol Clock Error Meter measures the symbol clock of the received DMR signal over one 30 ms slot. Outbound traffic (signal generated by BR) contains 144 symbols; inbound traffic (signal generated by mobile) contains 132 symbols. Symbol Clock Error measurements should not exceed ± 48 mHz. Meter can be viewed in Hz or PPM units.

2.5.13.B.19 Symbol Deviation

The Symbol Deviation Meter measures the deviation of the DMR signal at symbol time, normalized to the 1944 Hz symbol point. Symbol Deviation is measured over one 30 ms slot.

Outbound traffic (signal generated by BR) contains 144 symbols; inbound traffic (signal generated by mobile) contains 132 symbols. Symbol deviation measurements should be >1750 and <2138.

2.5.13.B.20 UUT Tx Bit Error

The UUT Tx BER Meter compares incoming DMR symbol data to a standard pattern to determine errors in signal processing.

Chapter 3 - DMR Channel Logger

3.1 INTRODUCTION

The DMR Channel Logger (390XOPT402) allows XML formatted information, referred to in this manual as XML files, to be relayed to and from a remote PC location and a Test Set. Each XML file contains processing instructions, a timestamp, and MAC header and MAC data blocks. When the PC and Test Set are connected, the Test Set sends any valid received DMR data to the PC in XML format. The PC receives the XML file, which can be saved to a file, edited and re-transmitted to the Test Set, or deleted.

NOTE

Received XML files can be viewed by either a text editor or a customer developed Viewing Application. This is an **option enabled* feature.

3.2 VIEWING APPLICATION

The following information is necessary to develop an internal viewing application:

- The Test Set Raw Data Service is 'listening' on TCP socket number 2222.
- The Test Set's IP address can be configured and accessed from the Network Utility Tile. Refer to the 3900 Series Operation Manual for use of this feature.
- Netcat application for transferring XML commands to and from the Test Set. Netcat is available at <http://www.vulnwatch.org/netcat/>.

3.3 CONNECTING EQUIPMENT

To use the User Data I/O Port, the PC and the Test Set must be operating on the same local network via an Ethernet cable. Once equipment is connected, XML files can be transmitted to and from the PC and the Test Set. In this configuration, the Test Set functions as a TCP socket "server" and the users PC application functions as a TCP "client." The port number used by the Test Set is 2222.

NOTE

The TCP socket on the PC should be opened in "blocking" mode so that XML data is not lost when it is sent to the Test Set. PC processing speed must be sufficient to allow it to accept the incoming data burst stream of XML lines.

3.4 DMR XML COMMAND STRUCTURE

This section describes DMR XML commands and command formatting instructions. This section is intended for users familiar with XML and therefore only describes XML commands specific to the DMR Data I/O Port feature.

The DMR RF Control Tile must be configured with the same settings defined in the XML command script prior to sending or receiving XML data.

3.4.1 <burst></burst>

The <burst> tag has the following attributes:

3.4.1.A **timestamp**

The timestamp command is an 8 digit hexadecimal number representing:

- On data sent to the Test Set: the time of transmission of the data in the burst.
- On data received from the Test Set: the time of reception of the burst.

The timestamp is optional on commands sent to the Test Set. It is present on data loads received from the Test Set

Times are all referenced from the first bit of the burst. They are relative to an arbitrary value, so timestamps should only be used is to compute the times between bursts in the same capture.

Timestamp resolution is 20 nsec, meaning a burst at 00000010 and a burst at 00000020 are 320 nsec apart (20 HEX - 10 HEX is 16 decimal, x 20 ns timestamp resolution is 320 nsec).

3.4.1.B **phys_channel**

This command specifies the channel (0 or 1) being transmitted or received.

- 0 = Channel 1
- 1 = Channel 2

3.4.1.C **direction**

This command specifies whether the signal is being transmitted (tx) or received (rx).

3.4.1.D **detect**

The field is used with receive only signals. Command indicates if received signal is valid or invalid.

3.4.1.E **type**

Indicates if data is an inbound service packet (isp) or outbound service packet (osp).

3.4.1.F **timeslot**

Indicates which timeslots in a TDMA system a specific data element is sent or received.

The command is skipped when it is received in a non-TDMA mode system or when command is not applicable to command usage.

3.5 FILTER PARAMETERS

3.5.1 <LogFilter></LogFilter>

The user may specify what types of information are to be sent from the Test Set by using the <LogFilter> tag. This tag requires using the parameter "phys_channel", which has the same meaning as the "phys_channel" of the <burst> tag.

The <LogFilter> tag requires using the following sub-tags (all sub-tags MUST be present), each of which is a boolean value (0/1 on/off true/false):

3.5.1.A <Environment></Environment>

The Environment tag controls the logging of Test Set configuration changes, such as received frequency, transmit frequency, etc.

3.5.1.B <Raw></Raw>

Raw controls the logging of raw octets received.

3.5.1.C <Protocol_Raw></Protocol_Raw>

Protocol_Raw controls the logging of raw protocol data (after decoding from the raw data stream but without interpretation).

3.5.1.D <Protocol_Cooked></Protocol_Cooked>

Protocol_Cooked controls the logging of protocol data with the data parsed into a more legible format.

3.5.1.E <Voice></Voice>

Voice controls logging of the voice data as sent to the vocoder.

3.5.1.F Example LogFilter:

```
<LogFilter phys_channel="1">
  <Environment>0</Environment>
  <Raw>0</Raw>
  <Protocol_Raw>0</Protocol_Raw>
  <Protocol_Cooked>0</Protocol_Cooked>
  <Voice>0</Voice>
</LogFilter>
```

NOTE

The following example DOES NOT WORK: it is missing some of the required subtags:

```
<LogFilter phys_channel="1">
  <Environment>0</Environment>
  <Raw>0</Raw>
</LogFilter>
```

THIS PAGE INTENTIONALLY LEFT BLANK.

Chapter 4 - Sample Setup File

4.1 DMR TEST SETUP SAMPLE CONFIGURATION FILE

The Test Set contains sample setup files which allow the user to easily configure the Test Set for DMR testing.

To load the DMR Loopback Setup file:

STEP PROCEDURE

1. Open the UTILS Store/Recall Tile.




Fig. 4-1 UTILS Store/Recall Tile

2. Select the DMR Loopback file.
3. Press the Recall Soft Key. Wait while the setup file is loaded.

STEP

PROCEDURE

4. After the DMR Loopback Setup file is loaded a user can customize parameters to meet UUT specifications.




Fig. 4-2 DMR Loopback Setup File

5. Refer to the 3900 Series Operation Manual for instructions about using the UTILS Store/Recall Tile to save the newly configured setup file.

Appendix A - DMR Terms and Abbreviations

avg	Average reading
BR	Base Radio
Bit Err	Bit Error Rate
CONFIG	Configuration
dB	decibel
dBm	decibel relative to 1 mW
dBV	decibel relative to 1 Volt
dBW	decibel relative to 1 Watt
DMR	Digital Mobile Radio
frq/freq	Frequency
FSK	Frequency Shift Keying
GEN	Generate/Generator
GHz	Giga Hertz
Hz	Hertz
kHz	kilo Hertz
Lvl	Level
max	Maximum reading
MHz	Mega Hertz
min	Minimum reading
Mkr	Marker
Mod	Modulation
ms/msec	Millisecond
mW	milli-Watt
RF	Radio Frequency
Rx	Receive
TOS	Top of Scale
Tx	Transmit
UTILS	Utilities
UUT	Unit Under Test
VNC	Virtual Network Client/Virtual Network Computing
W	Watt

THIS PAGE INTENTIONALLY LEFT BLANK.



**Part of CD # 6047
Revision M0
Jan 2020**

VIAVI Solutions, Inc.

North America:	1.844.GO VIAVI / 1.844.468.4284
Latin America	+52 55 5543 6644
EMEA	+49 7121 862273
APAC	+1 512 201 6534
All Other Regions:	viavisolutions.com/contacts